





K271
2P RCA phono jack (red & white)





K2760
2P RCA phono jack




K2711
3P RCA phono jack (red & white & yellow)





K2761
4P RCA phono jack





K272
4P RCA phono jack (red & white)





K27611
6P RCA phono jack




K273
8P RCA phono jack (red & white)





K2762
8P RCA phono jack





K27400
1P RCA phono jack with 4P mini din jack




K27662
4P RCA phono jack




K27403
3P RCA phono jack with 4P mini din jack




K276651
2P RCA phono jack





K27405
3P RCA phono jack with 4P mini din jack





K276652
3P RCA phono jack





K27410
3P RCA phono jack with 4P mini din jack



K276653
2P RCA phono jack



K27422
6P RCA phono jack



K276654
3P RCA phono jack

