



K306A
1/4" Mono plug to 3.5mm mono jack




K306C
1/4" Mono plug to 3.5mm stereo jack


K306F
1/4" Mono plug to 3.5mm mono jack



K306B
1/4" Stereo plug to 3.5mm stereo jack




K306J
1/4" Stereo plug to 3.5mm stereo jack




K306D
1/4" Stereo plug to 3.5mm mono jack

K306H
1/4" Stereo plug to 3.5mm mono jack


K306E
1/4" Mono plug to 1/4" stereo jack




K306K
1/4" Mono plug to 1/4" stereo jack




K306W
1/4" Stereo plug to 1/4" mono jack





K306N
1/4" Stereo plug to 1/4" mono jack




K307K
3.5mm Mono plug to 3.5mm stereo jack





K307E
3.5mm Mono plug to 3.5mm stereo jack




K307M
3.5mm Stereo plug to 3.5mm mono jack



K307F
3.5mm Stereo plug to 3.5mm mono jack




K307A
3.5mm Mono plug to 1/4" mono jack





K307N
3.5mm Mono plug to 1/4" mono jack


K307C
3.5mm Mono plug to 1/4" stereo jack



K307P
3.5mm Mono plug to 1/4" stereo jack




K307B
3.5mm Stereo plug to 1/4" stereo jack





K307R
3.5mm Stereo plug to 1/4" stereo jack



K307D
3.5mm Stereo plug to 1/4" mono jack



K307S
3.5mm Stereo plug to 1/4" mono jack





K308A
2.5mm Mono plug to 3.5mm mono jack



K308G
2.5mm Mono plug to 3.5mm mono jack

K308B
2.5mm Mono plug to 3.5mm stereo jack



K308H
2.5mm Mono plug to 3.5mm stereo jack

