



K309A


1/4" Mono plug to RCA jack

**K309M**


1/4" Mono plug to RCA jack

**K309B**

3.5mm Mono plug to RCA jack

**K309N**


3.5mm Mono plug to RCA jack

**K309C**

RCA plug to 1/4" mono jack

K309CA


RCA plug to 1/4" stereo jack

**K309P**

RCA plug to 1/4" mono jack

K309PA


RCA plug to 1/4" stereo jack

**K309D**

RCA plug to 3.5mm mono jack

K309DA


RCA plug to 3.5mm stereo jack

**K309E**


RCA plug to 3.5mm mono jack

K309EA


RCA plug to 3.5mm stereo jack

**K309G**


RCA jack to RCA jack

**K309Q**


RCA jack to RCA jack

**K309H**


1/4" Mono plug to PAL plug

**K309R**


RCA plug to PAL plug

**K309J**


1/4" Mono plug to PAL jack

**K309S**


RCA plug to PAL jack

**K309K**


3.5mm Mono plug to PAL plug

**K309T**

PAL jack to RCA jack

**K309L**

3.5mm Mono plug to PAL jack

**K309U**

PAL plug to RCA jack

