



RCA Phono Jack




K271
2P RCA PHONO JACK (RED & WHITE)





K2760
2P RCA PHONO JACK




K2711
3P RCA PHONO JACK (RED & WHITE & YELLOW)





K2761
4P RCA PHONO JACK




K272
4P RCA PHONO JACK (RED & WHITE)





K27611
6P RCA PHONO JACK





K273
8P RCA PHONO JACK (RED & WHITE)




K2762
8P RCA PHONO JACK




K27400
1P RCA PHONO JACK WITH 4P MINI DIN JACK




K27641
2P RCA PHONO JACK




K27405
3P RCA PHONO JACK WITH 4P MINI DIN JACK





K27661
2P RCA PHONO JACK




K27410
3P RCA PHONO JACK WITH 4P MINI DIN JACK





K27662
4P RCA PHONO JACK





K27420
3P RCA PHONO JACK



K27663
2P RCA PHONO JACK



K27422
6P RCA PHONO JACK



K27664
3P RCA PHONO JACK

