

01 INTRODUCTION

User Manual

Commercial Water Boiler



AVF THI INSTRUCTION
FOR FUTURE REFERENCE

-Electric catering water urns are manufactured in durable stainless steel and polished to give a long lasting finish. With proper care and management your new purchase will give you years of trouble free service. Constant simmering water enables hot drink.

02 IMPORTANT SAFEGUARDS

1. Read all Instructions carefully. Responsibility for failure cannot be acceptable. If any of these instructions are ignored.
2. Before using the water Urn, check whether the voltage indicated corresponds with the electric outlet (220V).
3. Do not connect the unit to an earthed socket.
4. Do not use the Water Urn if the cord or plug is damaged, it should be replaced before using.
5. If the Water urn malfunctions or has been damaged in any manner, return it to the nearest authorized service facility for examination and repair.
6. Always switch off before removing plug from the outlet.
7. Always switch off before trying to move the Water urn.
 - a. Remove the plug by grasping the plug. Do not pull the cord.
 9. Do not let cord hang over edge of counter.
8. Place the Water urn securely in center of counter or work.
9. Do not place the Water urn on or near hot surfaces.
10. Do not switch on the Water Urn, if the water tank is empty.
11. Do not place the Water Urn near gas stove, electric burner, heated oven.

PRODUCT INTRODUCTION

4. Put the Water Urn on lial stable surface keep it away from the edge 01 counter to avoid acclden
5. Close supervrson is necessary when any **appliance** is sed by or near children
- 6.00 nol allow cord to touch hot surface 01 the Water Ur
7. To protect **against** electnc shock ,do not immerse the Water Urn **in** water
- a. Unplug the **unit** from the socket .and cool lthe Water Urn all before **cleaning**
9. Switch OFF alter use and unplug the unit from lthe socket .
- 0.00 not use the Water Urn outdoor .



- 1.00 no overfill the Water urn With water **doing** so can lead to spillage as the water heats up and expands.
2. This **machine** should not be operated by persons With reduced physical ,sensory or mental capabilities ,or lack of expenence or knowledge ,unless they have been given supervision or instrcillon concerning the safe use of the appliance by a person responsible for **their** safety

SUITABLE PLUG

hina

B 2099-1 & GB 1002-1



plug: notavailable socket. not available
cordset 86517040

CIRCUIT DIAGRAM

