



































# Adaptor



<p><b>K309A</b> 1/4" MONO PLUG TO RCA JACK</p>  	<p><b>K309M</b> 1/4" MONO PLUG TO RCA JACK</p>  
<p><b>K309B</b> 3.5mm MONO PLUG TO RCA JACK</p>  	<p><b>K309N</b> 3.5mm MONO PLUG TO RCA JACK</p>  
<p><b>K309C</b> RCA PLUG TO 1/4" MONO JACK</p> <p><b>K309CA</b> RCA PLUG TO 1/4" STEREO JACK</p>  	<p><b>K309P</b> RCA PLUG TO 1/4" MONO JACK</p> <p><b>K309PA</b> RCA PLUG TO 1/4" STEREO JACK</p>  
<p><b>K309D</b> RCA PLUG TO 3.5mm MONO JACK</p> <p><b>K309DA</b> RCA PLUG TO 3.5mm STEREO JACK</p>  	<p><b>K309E</b> RCA PLUG TO 3.5mm MONO JACK</p> <p><b>K309EA</b> RCA PLUG TO 3.5mm STEREO JACK</p>  
<p><b>K309G</b> RCA JACK TO RCA JACK</p>  	<p><b>K309Q</b> RCA JACK TO RCA JACK</p>  
<p><b>K309H</b> 1/4" MONO PLUG TO PAL PLUG</p>  	<p><b>K309R</b> RCA PLUG TO PAL PLUG</p>  
<p><b>K309J</b> 1/4" MONO PLUG TO PAL JACK</p>  	<p><b>K309S</b> RCA PLUG TO PAL JACK</p>  
<p><b>K309K</b> 3.5mm MONO PLUG TO PAL PLUG</p>  	<p><b>K309T</b> PAL JACK TO RCA JACK</p>  
<p><b>K309L</b> 3.5mm MONO PLUG TO PAL JACK</p>  	<p><b>K309U</b> PAL PLUG TO RCA JACK</p> 