

## Electric Fence Light

The electric fence indicator light is installed directly onto the electric fence wires and will pulse every time the energizer pulses the HV, showing at a quick glance that there is power on the electric fence.



## Specifications

- Install it on your electric fence to indicate power status for peace of mind
- One directional viewing angle, allowing the light to shine into the secure area only. The status is not visible to external areas
- Working voltage between 3 kV and 12 kV approximately
- Dual stage design allows the intensity on the light to increase with the voltage giving a better indication of how much voltage is on the fence
- Can be installed between any earth and live wires
- Can be used with most electric fence energizers